| Problem solving and special applica | tion cartridge | |
|--|--|--|
| _ | | BENEFITS |
| | 7DM Replacement Cartridge: EV9607-01 | Demineralizing water filter for water with hig mineral content Removes total dissolved solids (TDS) by usir mix of cation and anion resin Especially useful on low capacity flash steame and warrmers that are not emptied each day Reduces scale build- up Sanitary cartridge replacement is simple, quich and clean. Internal filter parts are never expos to handling or contamination |
| INSTALLATION TIPS | OPERATION TIPS | A P P L I C A T I O N / S I Z I N G |
| Install vertically with cartridge hanging down Allow 2-1/2" clearance below the cartridge for easy cartridge replacement Flush cartridge by running water through filter for three minutes at full flow Use plastic tubing after DM cartridge | Change cartridges on a regular 6 month preventative maintenance program Change cartridges when capacity is reached or when pressure falls below 10 psi Always flush the filter cartridge at time of installation and cartridge change | Problem solving and special application cartric for extraordinary water conditions Capacity: 1,600 grains or 103,000 ppm To determine cartridge life, divide total capaci of cartridge (1,600 grains or 103,000 mg) by th TDS in grains per gallon (gpg) or milligrams liter (ppm), respectively |

7DM Replacement Cartridge

S P E C I F I C A T I O N S

Overall Dimensions: 20.75"H x 3.25"Diameter

Service Flow Rate: Maximum 0.5 gpm (1.9 Lpm)


Pressure Requirements: 10 - 125 psi (0.7 – 8.6 bar), non-shock

Temperature: 35 - 100°F (2 - 38°C)

No electrical connection required

Contents: Acid cation and base anion exchange resin

The contaminants or other substances removed or reduced by this drinking water system are not necessarily in your water. Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system. Systems certified for cyst reduction may be used with disinfected water that may contain filterable cysts.





purchase. See printed warranty for details. Everpure will provide a

Worldwide Headquarters: EVERPURE, LLC 1040 Muirfield Drive Hanover Park, Illinois 60133 Toll Free (800) 323 - 7873 Tel (630) 307 - 3030 http://www.everpure.com

copy of the warranty upon request.

In Europe: Pentair Water Belgium B.V./B.A. Industriepark Wolfstee Toekomstlaan 30 B-2200 Herentals BELGIUM TEL: +32.(0).14.283,500 FAX: +32.(0).14.283,505 In Japan: Hashimoto MN Bldg. 7F 3-25-1 Hashimoto Sagamihara-Shi Kanagawa 229-1103 JAPAN TEL: 81.(0)42.775.3011 FAX: 81.(0)42.775.3015